

THAT'SAUDIO

DIY STROBE DISC



- Cut out and stick onto similar size piece of card...and cut out centre circle for turntable spindle
- Place the strobe disc over the spindle of your turntable, so that strobe disc lays flat on platter.
- Turn your turntable on.
- With the platter spinning at the correct speed (e.g. 33rpm) then the strobe ring under a normal fluorescent light should appear to remain stationary.
- If strobe ring appears to be spinning then the speed of the platter will need to be adjusted.
- Adjust the *speed control* of your turntable until the appropriate band (33 / 45 / 78 rpm) appears stationary when the platter is spinning.
- If you are unable to locate / adjust speed control take turntable to a qualified hifi engineer

